



## LONGBOW ASSEMBLY GUIDE



1 Begin by attaching the upper limb to the top of the riser.



2 Firmly slide the tongue end of the limb into the riser. The signature on the limb should be facing the front of the riser.




3 Repeat with bottom limb (serial number decal facing back of riser).



4 Lay the string so that the short part of the finger protector is toward the top of the bow.




5 Place the large top loop of the string loosely around the top limb.




6 Slide the top loop down to create slack in the string.



7 Place the bottom loop of the string inside the notch of the bottom limb tip. Make sure the string is centered on the limb.




8 With the bow facing up, place the bottom limb under your thigh (above and behind your knee).



9 Grip the riser and pull it toward you while pushing the string loop away from you until it is in the notch of the top limb tip.



10 The string should be centered on back of the limbs. Your bow is now ready to shoot.



Stringing a bow incorrectly can cause limbs to break.



**Always unstring your bow when not in use. To unstring the bow, reverse the above process.**

**ARCHERYTAG.COM**

101 Archery Way, Ashley, IN 46705  
260.587.4500  
info@globalarchery.com



Archery Tag® and S.A.F.E. Archery® are registered trademarks of Global Archery Products, Inc. Registered in the U.S. and other countries. © 2022 Global Archery Products, Inc., All Rights Reserved.

