User manual AXIWI® AT-320
6 persons two-way (duplex) communication

With the AXIWI communication system, you have to setup one unit as a "Master". The other units have to be set up as a "Submaster" or a "Follower", depending if you want to be able to talk continuously or incidentally.
With a "Submaster" your speaking function is always activated.
With a "Follower" you have to manually activate and deactivate your speaking function.

In order to set up the AXIWI communication system, you have to make the following installation steps.

Set up as Master
1. Push and hold the volume up button.
2. Then push the 'on/off' button (approx. 1-2 seconds) while pushing the volume up button at the same time. The color of the LED light indicated the channel.
3. The AXIWI unit is set up in the 'Master' mode. The LED light will light up constantly.

Set up as Submaster
1. Push and hold the volume down button.
2. Then push the 'on/off' button (approx. 1-2 seconds) while pushing the volume down button at the same time.
3. The AXIWI unit is set up as "Submaster". The LED light of the chosen channel will flash quickly (quicker than in the 'Follower' mode) and the other LED lights will light up constantly.

Set up as Follower
1. Push the 'on /off' button (at least 2 sec.). The LED light of the chosen channel will flash. The AXIWI is set up as 'Follower'.
2. With the 'S' speaking button on the front, the speaking function can be activated and deactivated. Press the 'S' speaking button briefly to activate (and again) to deactivate the speaking function.
3. When the speaking function is activated, the LED light of the chosen channel will flash, the other LED lights will light up constantly.

Change the Channel
1. Push the volume up botton and hold it.
2. Push the 'S' botton briefly at the same time. Eash time you push the 'S' button, the LED light will change to the next color: the next channel. When you have selected the corret channel, release the colum up button.

1. Headset Port

2. USB Port

3. Channel LED

4. Volume Up

5. Multi-Funtional 'S' Button

6. Volume Down

7. On/Off Button

GlobalArchery.com/AXIWI

Global Archery - Official North American Distributor